CAUTION NOTICE DVX002-2013-CAU May 2013





HEAD OFFICE

Enterprise Drive Westhill Aberden AB32 6TQ T: +44 (0)1224 740145 F: +44 (0)1224 740172

WHE-3 Contactors Caution Notice DVX002-2013-CAU

Products Affected DO06864 Contactor, 15KW, 3 Pole, 5 off

Safety Issue

As a result of some service work done by Divex in the field it has been identified that main switchgear components in the WHE-3 Electrical Control Panel are under specified. Although the components have been supplied with the units it is necessary to request that the contactors are changed out with those supplied by Divex.

Corrective Action

- Divex has provided a full set of replacement contactors and guidelines to enable change over;
- Clients are required to make the necessary arrangements for change over of the contactors;
- Only suitably qualified Technicians should undertake the replacement exercise;

Technical Advice

All work to be carried out by a competent electrical person

Ensure Power Supply to WHE-3 has been properly isolated and locked off with P.T.W. in place.

GLOBAL

LOCATIONS Aberdeen Bremen Dubai Cape Town Perth Sydney The purpose of this change is to replace underrated contactors that were supplied in the previous contactor upgrade to the WHE-3 electrical cabinet.

The parts kit supplied should contain: DO06864 - CONTACTOR, 15KW, 3 POLE, 5 off

Replace the following components highlighted in drawings attached

<u>C5, C7, C8, C9, C10</u>

for a DO06864 (Lovato 15KW 3 pole contactor) and reuse existing DO04924 (Surge Suppressor)

Ensure all terminals are secure.

Perform Continuity and Insulation Resistance tests on all cables before restoring power and performing function test.



discover more www.divexglobal.com

Global Locations: Aberdeen | Bremen | Dubai | Cape Town | Perth | Sydney

CAUTION NOTICE DVX002-2013-CAU May 2013





HEAD OFFICE Enterprise Drive Westhill Aberden AB32 6TQ T: +44 (0)1224 740145 F: +44 (0)1224 740172

Serial Numbers Affected

WHE3/126/09	WHE3/127/09	WHE3/131/09	WHE3/132/10	WHE3/133/10
WHE3/134/10	WHE3/135/10	WHE3/136/10	WHE3/137/10	WHE3/138/10
WHE3/139/10	WHE3/140/10	WHE3/141/10	WHE3/142/10	WHE3/143/10
WHE3/146/11	WHE3/147/11	WHE3/148/11	WHE3/149/11	WHE3/150/11
WHE3/151/11	WHE3/152/11	WHE3/153/11		

Action to Prevent Recurrence

- Divex has carried out a design review and the technical details related to the Divex Part Number has been updated to ensure no further potential problems of this nature are experienced;
- Distribute Divex HSE Alert to all Divex locations;
- All Divex personnel associated with design and servicing of Dive Systems must be made aware of this incident prior to performing design work or service work on DSVs;
- Clients to confirm to Divex that the change over process has been completed stating Serial No.

Any queries on this issue should be addressed to:

Kevin Smith (General Manager – QHSE) – ksmith@divexglobal.com

Enterprise Drive, Westhill Industrial Estate, Westhill,

Divex Ltd.

LOCATIONS Aberdeen Bremen Dubai Cape Town Perth Sydney

GLOBAL

Aberdeen, Scotland, UK. AB32 6TQ Tel: +44 (0) 1224 740145 Fax: +44 (0) 1224 740172 E-Mail: ksmith@divexglobal.com

Signed:

Date: 30 May 2013

Kevin Smith General Manager – QHSE for and on behalf of Divex Ltd.

discover more www.divexglobal.com



Copyright 2013 Divex Limited. All Rights Reserved.

Head Office:Enterprise Drive, Westhill, Aberdeenshire, AB32 6TQ Tel: +44 (0)1224 740145 Email: info@divexglobal.com

men | Dubai | Cape Town | Perth | Sydney Global I

